# INSTRUCTIONS FOR CREATING SUBFORM: 5.4-DSCVA-Triennial

### Follow these steps to create the form fields:

### STEP 1: Create a Single Select field

**Description:** 5.4-T-DSCVA-13: Perform gas leakage test. Dry pipe systems shall be tested for gas leakage, using one of the following test methods:

Options: Yes, No

#### STEP 2: Create a Single Select field

**Description:** 5.4-T-DSCVA-13A: 1) A gas (air/nitrogen) pressure test at 40 psi (3.2 bar) shall be performed for 2 hours. (a) The system shall be permitted to lose up to 3 psi (0.2 bar)

Options: Yes, No

## STEP 3: Create a Single Select field

**Description:** 5.4-T-DSCVA-13B: During the duration of the test. (b) Gas leaks shall be addressed if the system loses more than 3 psi (0.2 bar) during this test.

Options: Yes, No

#### STEP 4: Create a Single Select field

**Description:** 5.4-T-DSCVA-13C: (2) With the system at normal system pressure, the gas source (nitrogen supply, compressor, or shop air) shall be shut off for 4 hours. If the low pressure alarm goes off within this period, the leaks shall be addressed.

Options: Yes, No

## STEP 5: Create a Single Select field

**Description:** 5.4-T-DSCVA-9: Perform test on quick opening device.

Options: Yes, No